




# Claudia looping



Monteringsvejledning/Monteringsanvisning/Montasjeanvisning/Installation instructions/  
Installationsanleitung/Asennusohje




Turn power  
OFF



**Please note:**  
**Serial connection**



Turn power  
ON






## Power supply:

Constant current **350mA**.

Note that the power supply **must be** constant current (350mA) and **not** 12V AC/DC.

Use Scan Products driver – art.no.: 12401, 12402 and 12403.



We refer to our website [www.scan-products.com](http://www.scan-products.com) regarding: products, documentation, approvals, dimmer overview, etc.